

### PC System Requirements











Ensure that your PC has the following before attempting to install the software.

- Microsoft Windows 10 or later.
- A maximum of 500MB of free disk space is required.
- For VisualAdrian, VisualFlonet and VisualPiper, 32-bit Microsoft Office Visio 2013 or higher must be installed.
- For CAPRE, Microsoft Office Excel 2013 or higher must be installed (N.B. CAPRE's physical properties calculation sheet will not work with 64-bit Excel).

**Note:** You must have Administration privileges to install the software.

1. Close any applications you have running before installing PEL.
2. Go the PEL website [www.pelsoftware.com](http://www.pelsoftware.com)
3. Download the file labelled 'PEL 23.1 Standalone Edition':

### Downloads for Process Engineering Software - PEL

	<b>PEL 23.1 Network Edition</b> Summary: No summary available Software - English - 2021-11-11 - 319,71 MB	 <a href="#">ZIP</a>
	<b>PEL 23.1 Standalone Edition</b> Summary: No summary available Software - English - 2021-11-11 - 274,70 MB	 <a href="#">ZIP</a>
	<b>PEL Safety HRA 1.4</b> Summary: No summary available Software - English - 2023-01-25 - 24,88 MB	 <a href="#">ZIP</a>
	<b>PEL Network Installation Procedure</b> Summary: No summary available Instruction - English - 2023-02-09 - 0,22 MB	 <a href="#">PDF</a>
	<b>PEL Standalone Installation Procedure</b> Summary: No summary available Instruction - English - 2022-04-12 - 0,13 MB	 <a href="#">PDF</a>

4. After downloading, unzip the file and double-click the file **Setup-PEL23.1.exe**.
5. You may be prompted for your administrator password.
6. Follow the instructions, selecting the **Typical** option (or **Custom** if you wish to add Flonet, Adrian, Piper or remove other programs) which will take you through the self-explanatory installation procedure.


### Obtaining a PEL Licence

1. Run the PEL Licence Manager by clicking **Start > PEL Launcher** then click the icon **Licence & Settings**.
  - Click the tab **Request Licence**,
  - Enter your Name, your Company Name and your Contact Telephone Number,
  - Click the **Generate Request** button.

This will generate a licence request code.


2. E-mail this code to [pel.support@tuv.com](mailto:pel.support@tuv.com).

A Licence file (PEL.LIC) will be sent to you normally within the next 24 hours.



### Installing the PEL Licence file

1. When you receive your PEL licence, save it to a temporary location on your PC.
2. Run the PEL Licence Manager by clicking **Start > PEL Launcher** then click the icon **Licence & Settings**.
3. Click the tab **Install/Renew Licence**.
4. Click **Browse** to locate the **PEL.LIC** file.
5. Click **Install Licence**.



This program is developed, maintained and supported by PEL Support Services, TÜV Rheinland. We run a Hotline telephone and email service to answer any queries about the PEL products. You can contact us:

E-mail: [pel.support@tuv.com](mailto:pel.support@tuv.com)  
Telephone: +44 (0)1925 74 1126  
Website: [www.pelsoftware.com](http://www.pelsoftware.com)

Post: PEL Support Services  
TÜV Rheinland Ltd  
Wilderspool Park, Greenall's Avenue  
Warrington, Cheshire, WA4 6HL