

PC System Requirements











Ensure that your PC has the following before attempting to install the software.

- Microsoft Windows 10 or later.
- A maximum of 500MB of free disk space is required.
- For VisualAdrian, VisualFlonet and VisualPiper, 32-bit Microsoft Office Visio 2013 or higher must be installed.
- For CAPRE, Microsoft Office Excel 2013 or higher must be installed (N.B. CAPRE's physical properties calculation sheet will not work with 64-bit Excel).

Note: You must have Administration privileges to install the software.

1. Close any applications you have running before installing PEL.
2. Go the PEL website www.pelsoftware.com
3. Download the file labelled 'PEL 23 Standalone Edition':

Downloads for Process Engineering Software - PEL

| | | |
|---|---|---|
|  | PEL 23 Network Edition Summary: No summary available Software - English - 2021-11-11 - 319,71 MB |  ZIP |
|  | PEL 23 Standalone Edition Summary: No summary available Software - English - 2021-11-11 - 274,70 MB |  ZIP |
|  | PEL Safety HRA 1.4 Summary: No summary available Software - English - 2023-01-25 - 24,88 MB |  ZIP |
|  | PEL Network Installation Procedure Summary: No summary available Instruction - English - 2023-02-09 - 0,22 MB |  PDF |
|  | PEL Standalone Installation Procedure Summary: No summary available Instruction - English - 2022-04-12 - 0,13 MB |  PDF |

4. After downloading, unzip the file and double-click the file **Setup-PEL23.exe**.
5. You may be prompted for your administrator password.
6. Follow the instructions, selecting the **Typical** option (or **Custom** if you wish to add Flonet, Adrian, Piper or remove other programs) which will take you through the self-explanatory installation procedure.


Obtaining a PEL Licence

1. Run the PEL Licence Manager by clicking **Start > PEL Launcher** then click the icon **Licence & Settings**.
 - Click the tab **Request Licence**,
 - Enter your Name, your Company Name and your Contact Telephone Number,
 - Click the **Generate Request** button.

This will generate a licence request code.


2. E-mail this code to pel.support@tuv.com.

A Licence file (PEL.LIC) will be sent to you normally within the next 24 hours.



Installing the PEL Licence file

1. When you receive your PEL licence, save it to a temporary location on your PC.
2. Run the PEL Licence Manager by clicking **Start > PEL Launcher** then click the icon **Licence & Settings**.
3. Click the tab **Install/Renew Licence**.
4. Click **Browse** to locate the **PEL.LIC** file.
5. Click **Install Licence**.



This program is developed, maintained and supported by PEL Support Services, TÜV Rheinland. We run a Hotline telephone and email service to answer any queries about the PEL products. You can contact us:

E-mail: pel.support@tuv.com
Telephone: +44 (0)1925 74 1126
Website: www.pelsoftware.com

Post: PEL Support Services
TÜV Rheinland Ltd
Wilderspool Park, Greenall's Avenue
Warrington, Cheshire, WA4 6HL